

Coopercraft Pens

Pens That Help You Score!™

Replacing Points and Reservoirs Instructions

Points:

1. Use tweezers/needle nose pliers to remove used point then discard.
2. Insert new point into pen adapter with hand or tweezers.
3. Point should begin to receive ink from reservoir.

Reservoirs:

1. Remove end plug from bottom of pen.
2. Remove old reservoir with tweezers or needle nose pliers then discard.
3. Remove and replace nib point.
4. Insert new reservoir into pen. If necessary, cut-off excess part of reservoir extending from end of pen using scissors or blade knife.
5. Dip new reservoir into Ink Bottle.
6. When ink is visible in bottom of reservoir, remove reservoir from Ink Bottle.
7. Place inked end of reservoir into pen barrel towards the nib point and replace end cap.
8. Turn pen upside down and it will re-ink within a couple of minutes.